



Fiberprime, Inc.

www.fiberprime.com

Tel: 1-613- 7214921

Email: info@fiberprime.com

Fax: 1-613-8289398

User Manual (draft)

L-band 20/21dBm EDFA Instrument in Benchtop

(EDFA-L-PG, version 1.0a. April 6, 2015)



Safety

Do not under any circumstances look at the output of the optical port unless the equipment is turned off ! Containing a high power invisible pump laser and amplified signal light, use the utmost care when changing connections, and always turn the unit completely off before inspecting or cleaning any connectors which are attached to the unit's output.



Laser Safety and Electrical Compliance

- Maximum output power 500mW. Wavelength 960-1680nm. Max wavelength range: 1520-1620nm.
 - Class IIb laser product. Complies with 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice No. 50, dated June 24, 2007.
 - Class 3B laser product. Complies with IEC 60825-1, 60825-2 laser safety standards.
- Complies with CE and other standards for electrical safety and EMI.
- The internal AC-DC power supply module and optical EDFA module meet safety standards.

Introduction

L-band EDFA instrument in benchtop. Standard max output power: typical 20dBm version or typical 21dBm version. Gain Flat. User can flexibly adjust EDFA output power, gain, and even pump current from instrument front panel locally or from computer through RS-232 remotely. It is designed for booster and line amplifier, it can also be used as pre-amplifier. Mid-stage-access is available at much more cost.

EDFA-L-PG series optical fiber amplifier can operate at three control modes:

- **Constant power:** the EDFA maintains user-selected stage-specific output power.
- **Constant gain:** The EDFA maintains user-selected stage-specific gain.
- **Constant current:** The EDFA maintains user-selected laser diode-specific drive current of pump lasers. Only available at remote mode at this moment. Local mode is available in much longer lead time.

Front panel: Optical input and output ports with two fiber adapters (LC/PC interface by default, other types are also available). 2x20 LCD. 5x4 numeric and arrow keypad. Keylock switch to enable pump laser.

Rear panel: 100-120V/200-240V AC input with power switch. RS-232 adapter with switch for remote control. Firmware adapter with switch for updating firmware.

Aluminum Enclosure dimension: 259(w) × 147(h) x 300(d) mm.

Operating temperature: from 0 to 40°C degree (higher temperature >50°C degree should be also ok).

Key optical features:

- Constant output power mode: Max 20dBm or 21dBm at large input signal (typically > 0dBm). Best for high input and may be ok for medium input power.
(Note: If set max output power 20dBm for 20dBm model or set 21dBm for 21dBm model, input power should be over 0dBm typically, otherwise target output power may not be reached, and pump laser drive current of EDFA may exceed max allowed value, especially at longer wavelength. At front panel, max allowed set power is 22dBm for 21dBm-version EDFA; max set allowed power is 21dBm for 20dBm-version EDFA. No such restriction if set power at remote mode.)
- Constant gain mode: Best for medium input and is ok for small input power. Better performance at <20dB gain setting at near 0dBm input, especially at shorter wavelength. It also works at lower gain with high input power.
(Note: If gain is set too high, output power may exceed max 20dBm or 21dBm, then target gain may not be reached, and pump laser drive current of EDFA may exceed max allowed value, especially at longer wavelength. At front panel, max allowed set gain is 27dB. No such restriction if set gain at remote mode.)
- Noise figure: 5dB typical. Normally <6dB. Noise figure is a little bit higher at shorter wavelength.
- Gain flatness: <1dB typically, at reasonable input power range (not too low input power).

Applications:

- Instrumentation, Testing
- Metro and Long-haul communications and optical switching systems.
- LANS and MANs
- Laboratory use
- Cable television

Standard package includes:

- Equipment enclosure including EDFA system and power supply module.
- One power cable with AC plug type fitting your country.
- Spectrum graphs of gain, noise figure, and output power tested at several input powers (-29, -24, -19, -14, -9, -4, 1, 6dBm by default) over 1570-1603nm. One test data sheet of these graphs.
- User manual (draft)

Please tell us your preferred AC plug type. Our available AC power plug types are B, C, G, I. Type B is mainly used in North and Centra America, Japan, Taiwan, and Thailand. Type C is mainly used in Europe, South America & Asia. Type G is mainly used in UK, Ireland, Malaysia, Singapore, & Hong Kong. Type I is mainly used in Australia, New Zealand, China & Argentina. See full list at <http://www.worldstandards.eu/electricity/plug-voltage-by-country/>



Inspection

Before shipment, the unit has been found to be free of defects. The instrument part number and serial number can be found on a label located at the back of the unit. The instrument history is filed at the factory by part number and serial number.

Assembling Instrument after you receive the instrument

- Connect your own two fiber patchcords to the adapters on front panel. (Please Do Not screw FC connector into FC adapter too hard which may make connector dirty. To keep internal fiber connectors clean and long lifetime, we recommend you try to keep fiber jumpers connected on front panel adapters permanently).
- Plug power cable into AC inlet on rear panel.

Getting Started

- At the rear panel of equipment, turn on power switch above AC inlet.
- On rear panel, “RS-232” switch should be at “Local” position, “Firmware” switch should be at “Normal” position.
- Insert key into key-lock switch on front panel, turn on the key-lock switch to enable EDFA.

Note: If there is reflection back to EDFA instrument, you cannot get max output power. For example, for near 4% reflection from far end of fiber jumper FC/PC connector or from optical receiver with air gap, you cannot get more than 16dBm output power. This arrangement is for human safety. To reach max power, use APC connector at open end, or add isolator/attenuator.

Operation Instruction (Local mode)

- After power on, the equipment is set at constant 10dBm output.
- Press “MODE”, you can toggle between P (constant output power) mode and G (constant gain) mode.
- You can change output power or gain from keypad. For example, type in “19.51”, press “ENTR” key, you will get 19.51dBm output in P mode, or 19.51dB gain in G mode.
- Arrow keys: You can also adjust power or gain value by pressing arrow keys, changed value will be executed after pressing “ENTER” key.
- “ESC” key: Cancel all the digits you just typed (not pressed “ENTER” key yet), LCD will show current power/gain value.
- “-/BSC” key: Negative sign: If you have not typed any digit yet, LCD will show negative sign “-“. Or backspace function: Cancel the last digit you just typed (not typed “ENTER” key yet).
- “OPTION” key: After press this key, LCD will show operating status for few seconds, then go back to display of regular info.



- If your keypad is locked probably due to typing error, turn “RS-232” switch to “Remote(Reset)” position, then quickly turn back to “Local” position. The internal microprocessor will reset to factory default condition, then keypad should be unlocked.
- To avoid degrading pump laser, it is not recommended EDFA work at max output power with low input power. When set power/gain is too high especially at low input power, the pump laser current may exceed max allowed value, LCD will show “Alarm: Too high current” at the 2nd line. To avoid degrade pump laser, please reduce output-power/gain or increase input power accordingly. Sometimes, this alarm info cannot display on LCD in time, you may press “OPTION” key to get up-to-date status.

Remote Control

For remote control, turn “RS-232” switch to “Remote” position. Keep “Firmware” switch at “Normal” position. Link DB9-male to DB9-female cable between computer RS-232 serial port and instrument “RS-232” port. Run HyperTerminal program on your computer. Operation instruction is available by email upon request.

Update Firmware

If you need our updated software later, we can email you software, you download it to the equipment internal flash memory. Turn “Firmware” switch to “Download” position, turn “RS-232” switch at “Remote” position. Link DB9-male to DB9-female cable between computer RS-232 serial port and instrument “Firmware” port. Operation instruction is available by email upon request.

Cleaning optical connectors

After optical connectors plug in and pull out many times at front panel adapters, the connector may not be easily cleaned, so we recommend that you keep external fiber jumpers connected on front panel, and clean the fiber jumper connectors of far ends. You can unscrew the optical adapter plate from right end of front panel, remove internal optical connectors, then use traditional method to clean these connectors, see <http://www.lightwavestore.com/store/product.php?productid=20270&cat=369&page=1>.

Warranty: one year after delivery.

See details at <http://www.lightwavestore.com/warranty%20and%20technical%20support.htm>

Note: Never open the instrument enclosure, or warranty will be voided.

Ordering Information

P/N: EDFA-L-20-PG-1-LC: 20dBm output with LC/PC adapters (1: without mid-access stage).

P/N: EDFA-L-20-PG-1-FA: for 20dBm output with FC/APC adapters(without mid-access stage).

P/N: EDFA-L-21-PG-1-FP: for 21dBm output with FC/PC adapters(without mid-access stage).

Appendix 1: Amplifier Layout

Figure 1 shows the functional layout of the amplifier. Table 2 describes the labeled ports and Monitor Photodiodes (MPDs).

Note: Basic L-band EDFA instrument is without MSA (Mid Stage Access) and only contains one stage of gain.




Figure 1: Functional Block Diagram

Table 2: Amplifier Ports and MPDs

Name	Color	Descriptio
Port A	Blue	Input to Amplifier, Input to Stage 1
Port B	Green	Output to Mid-Stage Access (MSA), Output of Stage 1
Port M1	Black	Optical Monitor of Port B (approximately 20dB lower than Port B when VOA=0dB)
Port C	Orange	Input from MSA (See IOE Specifications for MSA loss), Input to Stage 2
Port D	Red	Output of Amplifier, Output of Stage 2
Port M2	Brown	Optical Monitor of Port D (approximately 18dB lower than Port D)
MPD1	-----	Monitor Photodiode of Port A
MPD2	-----	Monitor Photodiode of Port B, before VOA offset (MPD2 power equals Port B power plus VOA attenuation)
MPD3	-----	Monitor Photodiode of Port C
MPD4	-----	Monitor Photodiode of Port D



Appendix 2: Specifications(draft)

Note: Following draft specifications are for max-21dBm amplifier with MSA (Mid-Stage Access). For our standard EDFA amplifier without MSA, specifications should be similar.

Note: Optical power test is on internal fiber connectors. So gain result only includes one connector loss.

L-BAND BOOSTER AMPLIFIER OPTICAL SPECIFICATION at constant output power mode

SPECIFICATION	MINIMUM	TYPICAL	MAXIMUM	UNITS
Bandwidth	1570	—	1603	—
Total input power	-12	—	8	dBm
Total output power	—	21	—	dBm
Gain ripple (30° to 45° C)	—	—	1.0	dB
Gain ripple (0° to 70° C)	—	—	1.5	dB
Noise figure (at 5dBm total input power)	—	—	8	dB
Mid-stage loss	—	—	7 (can be much higher)	dB
Polarization Mode Dispersion (PMD)	—	—	0.4	ps
Polarization Dependent Gain (PDG)	—	—	0.3	dB
Transient suppression time with 3dB power add/drop	—	50	100	μs
Maximum excursion with 3dB power add/drop	—	—	0.5	dB
Transient suppression time with 6dB power add/drop	—	50	100	μs
Maximum excursion with 6dB power add/drop	—	0.5	1.0	dB
Laser classification	Class 3B under IEC/EN 60825-1			



L-BAND IN-LINE AMPLIFIER OPTICAL SPECIFICATION at constant gain mode

SPECIFICATION	MINIMUM	TYPICAL	MAXIMUM	UNITS
Bandwidth	1570	—	1603	—
Total input power	-22 (can be much lower as preamp)	—	—	-2
Total output power	—	21	—	dBm
Gain ripple (30° to 45° C)	—	—	1.0	dB
Gain ripple (0° to 70° C)	—	—	1.5	dB
Noise figure (at -5dBm total input power)	—	—	6.5	dB
Mid-stage loss	—	—	10 (can be much higher)	dB
Polarization Mode Dispersion (PMD)	—	—	0.4	ps
Polarization Dependent Gain (PDG)	—	—	0.3	dB
Transient suppression time with 3dB power add/drop	—	50	100	μs
Maximum excursion with 3dB power add/drop	—	—	0.5	dB
Transient suppression time with 6dB power add/drop	—	50	100	μs
Maximum excursion with 6dB power add/drop	—	0.5	1.0	dB
Laser classification	Class 3B under IEC/EN 60825-1			

Fiberprime, Inc.

Tel: 1-613-7214921

E-mail: info@fiberprime.com, Fax: 1-613-8289398

Ottawa, Ontario, K2H 1A1, Canada

All information contained herein is believed to be accurate and is subject to change without notice. No responsibility is assumed for its use. Fiberprime, Inc. reserves the right to make changes, without notice, to product design, product components, and product manufacturing methods. Some specific combinations of options may not be available. Please contact Fiberprime, Inc. for more information.
© Fiberprime, Inc. All rights reserved.
Rev.1a 6/04/2015 Printed in Canada